



NOTES:

1. PLACE CDF TO FULL WIDTH IN UNIFORM LAYERS NOT EXCEEDING 300mm UNTIL IT REACHES CROWN OF PIPE. AFTER THAT MATERIAL CAN BE PLACE FULL DEPTH
2. USE TEMPORARY PLATING OR OTHER MEANS OF SUPPORTING TRAFFIC LOADS TO PROVIDE SAFE DRIVING SURFACE FOR TRAFFIC UNTIL PAVEMENT MATERIAL IS REPLACED
3. THE OWNER/DEVELOPER'S CONSULTING ENGINEER MAY PROVIDE AN ALTERNATE DESIGN TO PROTECT THE AC PIPE UTILIZING A MINIMUM OF 4 JOINTS.

REGIONAL DISTRICT  
OF NORTH OKANAGAN

9848 Aberdeen Road, Coldstream, BC V1B 2K9  
PH: 250-550-3700 FAX: 250-550-3701



TITLE

AC PIPE  
CROSSING

DATE

MAY 2014

SCALE

N.T.S.

DRAWING No.

RDNO-04

REV.

4